myPDFmanuals

You can read the recommendations in the user guide, the technical guide or the installation guide for SONY CYBER-SHOT DSC-W120. You'll find the answers to all your questions on the SONY CYBER-SHOT DSC-W120 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual SONY CYBER-SHOT DSC-W120
User guide SONY CYBER-SHOT DSC-W120
Operating instructions SONY CYBER-SHOT DSC-W120
Instructions for use SONY CYBER-SHOT DSC-W120
Instruction manual SONY CYBER-SHOT DSC-W120

SONY

3-068-187-**11**(1)

Digital Still Camera

Operating Instructions

Before operating the unit, please read this manual thoroughly, and retain it for future reference.

Owner's Record

The model and serial numbers are located on the bottom. Record the serial number in the space provided below. Refer to these numbers whenever you call upon your Sony dealer regarding this product.

Model No. DSC-S75

Serial No. _____

Cyber-shot InfoLITHIUM MEMORY STICK ™

DSC-S75

©2001 Sony Corporation

Your user manual
SONY CYBER-SHOT DSC-W120

Manual abstract:

10 Setting the date and time . 15 Inserting the "Memory Stick" . 17 Recording still images as uncompressed files (TIFF) . 56 Creating Clip Motion Files . 56 Setting the distance to the subject . 58 Recording images in macro . 58 Adjusting the exposure (EXPOSURE) 59 Adjusting the white balance (WHITE BALANCE) 60 Enjoying picture effects (P. EFFECT) 61 Recording the date and time on the still image (DATE/TIME) . 61 Using the spot light-metering function 62 Basic operations B Recording Recording still images . 19 Recording moving images 26 B Playback Playing back still images .
28 Playing back moving images 29 Viewing images using a personal computer 31 Image file storage destinations and image files 38 B Various playback Playing back three or nine images at once 63 Enlarging a part of the still image (Zoom and trimming) . 64 Playing back the still images in order (SLIDE) 65 Rotating a still image (ROTATE) . 66 Viewing images on a TV screen . 66 Advanced operations Before performing advanced operations How to use the mode dial 40 How to use the control button . 41 How to use the jog dial .
42 Setting the image size (IMAGE SIZE) 47 B Editing Deleting images (DELETE) 67 Preventing accidental erasure (PROTECT) . 68 Changing the recorded still image size (RESIZE) . 70 Copying images (COPY) 71 Selecting still images to print (PRINT) . 72 Dividing a moving image file (DIVIDE) . 74 Changing the setup settings (SETUP) .
76 B Various recording Recording with the exposure fixed (AE LOCK) 49 Recording with the manual adjustments 50 Records images according to shooting conditions (SCENE SELECTION) . 51 Recording two images continuously . 52 Recording still images for e-mail (E-MAIL) . 53 Adding audio files to still images (VOICE) . 54 Recording text documents (TEXT) . 55 6 Additional information Precautions 79 On "Memory Sticks" 80 About "InfoLITHIUM" battery pack 81 Using your camera abroad 82 Troubleshooting 83 Warning and notice messages . 89 Self-diagnosis display . 91 Specifications 92 Display window indicators . 93 LCD screen indicators 94 Index . 97 7 Getting started Identifying the parts See the pages in parentheses for details of operation.

A Shutter button (19) (27) B Self-timer (23) (27)/ AF illuminator (25) C Photocell window for flash G Built-in microphone Do not touch while recording. H Accessory shoe I Hook for lens cap/strap J Flash (24) K Speaker L ACC (Accessory) jack M USB jack (33) (35) N A/V OUT jack (66) Do not block while recording with the flash. D Finder window E Lens When cleaning the lens, first return the lens to the fully retracted position and turn off the power, then gently wipe the lens. F Tripod receptacle (bottom surface) Audio output is monaural. O Lens cap (supplied) Use a tripod with a screw length of less than 5.5 mm (7/32 inch). You will be unable to firmly secure the camera to tripods having longer screws, and may damage the camera. Be sure to remove the lens cap before recording..

Your user manual
SONY CYBER-SHOT DSC-W120